

300
312

314

320

310

format

format

322

Attribute	Description	Initial value
Job ID	Job ID	JobID
PCM ID	ID of the PCM through which the job was received	Null
Personality	Personality of the PCM through which the job was received	Null
PCM Priority	Priority of the PCM through which the job was received	Null
MUX receive byte count	Number of bytes received by the MUX through calls to the apSPIDData routine by a primary source PCM. This includes all PCMs except the despooler (it is not a primary source PCM).	0
URL of the job	URL of the job (pull print only)	Null
Output request attribute for the job	Output requested by PCM for tile job(Printer, Spooler, Either)	PRINTER
Output assignment attribute	Output assignment attribute for the job (Printer, Spooler, Wait, Rejected)	Null
File format indicator (PDF)	File format indicator (PDF)	NORMAL
Mux Job State	State of the job in the MUX	Unknown
Spooler Job State	State of the job in the spooler	NotSpooled
Interpreter Job State	State of the job in the interpreter	WaitingFor Job
Engine Job State	State of the job in the engine	WaitingFor Job
PMDD bytes read	This is the number of bytes read by the interpreter through calls to the PMDD Read routine.	0
MUX printer output status	Status of output to printer (not started, in progress, completed)	NotStarted
MUX Spooling status	Status of job being spooled (not started, in progress, completed)	NotStarted
Timestamp	Timestamp (printer up time) of last attribute update	Uptime

Fig. 3

800

7

820

812

810

814

Process	From State	To State	Changed by
MUX	Unknown	Pending Printer	MUX OS Thread
	Unknown	Pending Any	MUX OS Thread
	Unknown	Pending Spooler	MUX OS Thread
	Unknown	Pending Pull Print	Pull Print wppSubmitJob
	Pending Printer	Receiving Data	MUX OS Thread
	Pending Any	Receiving Data	MUX OS Thread
	Pending Spooler	Queued to Spool	MUX OS Thread
	Pending Any	Queued to Spool	MUX OS Thread
	Queued to Spool	Pending Printer	MUX OS Thread
	Receiving Data	Done	MUX apsPDLEnd
Spooler	Not Spooled	Spooling Can Despool	sp-open
	Spooling Can Despool	Spooling / Despooling	sp-coj
	Spooling Can Despool	Waiting to Despool	sp-coj
	Spooling / Despooling	Despooling	Despool PCM
	Not Spooled	Spooling Can't Despool	sp-open
	Spooling Can't Despool	Waiting to Despool	sp-coj
	Waiting to Despool	Despooling	Despool PCM
	Despooling	Done	Despool PCM
	any	any	event announce callback
	any	any	event announce callback
Interpreter Engine	any	any	any

any

Fig. 8

910

912

914

900
920

Attribute ID	Type	Rel.	RO/ RW	IPP	SNMP	Notes
JM-ATTR-JOB-ID	Int	1	RO			Set by JM.
JM-ATTR-PCM-ID	Int (Enum)	1	RW			Set by MUX.
JM-ATTR-PCM-PERSONALITY	Int (Enum)	1	RW			Set by MUX.
JM-ATTR-PCM-PRIORITY	Int	1	RW			Set by MUX.
JM-ATTR-SPOOLED-BYTES	Int	1	RW			Set by MUX.
JM-ATTR-URL	String	1	RW			Set by WPP.
JM-ATTR-OUTPUT-REQUEST	Int (Enum)	1	RW			Set by MUX. Enum will contain PRINTER, SPOOLER, WAIT, REJECTED. Others will be added as needed.
JM-ATTR-FILE-FORMAT	Int (Enum)	1	RW			Set by MUX. Enum will contain at least UNKNOWN and PDF. Others will be added as needed.
JM-ATTR-MUX-STATE	Int (Enum)	1	RW			Set by MUX. Enum will be created to list the possible states.
JM-ATTR-SPOOLER-STATE	Int (Enum)	1	RW			Set by SPOOLER. Enum will be created to list the possible states.
JM-ATTR-INTERPRETER-STATE	Int (Enum)	1	RO			Set by JM. Enum will be created to list the possible states.
JM-ATTR-ENGINE-STATE	Int (Enum)	1	RO			Set by JM. Enum will be created to list the possible states.
JM-ATTR-JOB-STATE	Int (bitfields or array of int's?)	1	RO	Yes		Done by JM. Convert from JM-ATTR * STATE attributes
JM-ATTR-PAGES-SUBMITTED	Int	1	RO			Set by JM. This is the number of pages submitted into the pipeline by the interpreter (incremented once for each page, regardless of the copy count).
JM-ATTR-TOTAL-PAGES-IN-JOB	Int	1	RO			Set by JM. This is the total number of pages, including all copies of each page, which have been submitted into the pipeline.
JM-ATTR-TOTAL-PAGES-STACKED	Int	1	RO			Set by JM. This is the total number of pages that have been stacked by the engine (incremented for each copy of a page).
JM-ATTR-RECEIVED-BYTES	Int	1	RW			Set by MUX. The MUX should ensure that this is not doubled when we are spooling (ie, the bytes should only be counted when they are received from the host, not from the spooler).
JM-ATTR-BYTES-PROCESSED	Int	1	RW			Set by PMDD
JM-ATTR-LAST-MODIFIED	Int	1	RO			Set by JM. This is a timestamp (or count) used to tell if data modified since last checked this value.
JM-ATTR-CANCEL-INITIATOR	Int (Enum)	1	RW	Yes	Yes	Set by cancel of cancel. This is who requested the cancel (operator, the device)
JM-ATTR-CANCEL	Int	1	RW			Set by JM (or IPDS?). 0 if not cancelling, 1 if cancel initiated
JM-ATTR-OPEN-COUNT	Int	1	RO			Set by JM. Not read by others. Used to know how many people have this handle open (have not called destroy yet).
JM-ATTR-COPY-SET	Int	1	RO			Set by JM. This is the set for the last page stacked if doing collation.
JM-ATTR-COPY-COUNT	Int	1	RO			Set by JM. This is the copy count for the last page stacked if doing collation.
JM-ATTR-COLLATE	Int	1	RW			True if collated job, false otherwise.
JM-ATTR-DUPLEX	Int	1	RW			True if job is duplex, false otherwise.

REQUESTER

FALSE

ENUM

Fig. 9

USER